



Hybrid Resilient Installation Guide – 2G Locking System NXWOOD Collection

Expansion:

All floors naturally expand and contract and therefore require expansion space around perimeter walls and any vertical obstructions. The expansion space should be equal to the thickness of the material being used or a minimum of 1/2".

Tools Required:

Marker/Pen, Tape Measure, Chalk Line, Square, 6ft Level or Straight Edge, White Mallet, Hammer, Tapping Block, Last Board Puller, Miter Saw, Jamb Saw, Table Saw, Jig Saw, and Spacers/Shims.

Note: The only approved additional underlay that can be used is FuzSonic Universal, FuzSonic Universal MB, or Dura Son MB which are ultra-high density and thin. DO NOT use additional layers of unapproved underlay as this will cause joints to flex and eventually break.

A 6 mil. poly moisture barrier is recommended to minimize any potential MVER or moisture issues.

Job Preparation:

- Calculate the surface area required and add 5-10% and then round up to the nearest full carton.
- Acclimatize flooring for temperature by spreading out sealed packages in room/ environment where the floor will be installed at a room temperature between 16°C (60°F) and 27°C (80°F), and relative humidity between 35-65% RH for 48 hours. Ensure packages remain sealed/closed during acclimation and until ready to install.
- Will perform in extreme temperature conditions: -30°C-80°C (-22°F-176°F).
- Ensure subfloor is clean, flat, sound, dry and free of any debris that might impact installation. The subfloor must be level/flat to 3/16" per 10ft radius
- If height differences do exist, peaks will need to be ground down and valleys will need to be filled with patching compound.

- Remove any existing quarter round and undercut door jambs allowing the flooring to float under the jamb provide a preferred aesthetic.
- Check flooring planks for any visual defects in structure or aesthetics. Planks installed with visual defects are not covered under warranty.


Note: The installer is the final inspector of product and responsible for assessing subfloor and job site conditions to ensure compliance with referenced standards. If conditions or materials do not meet requirements, installation must not proceed until corrected. Installation instructions must be read thoroughly prior to starting. If the installer identifies any manufacturing, or visible concerns, they must not install the material and should contact the retailer. Once a plank is installed, it is deemed accepted by the installer and/or homeowner, even if the homeowner is not present. The installer is fully responsible for all installed flooring.

Subfloor Requirements:

Wood subfloors must be 3/4" thick, dry and well secured with moisture content < 12%. If installing over a crawl space install 6 mil. poly over the dirt in the crawlspace. Ensure the crawlspace is adequately ventilated. Wood subfloors must be nailed down or screwed down every 6" along the joist to avoid squeaking.

Concrete subfloors must be fully cured for at least 60 days. The subfloor must remain dry all year round. Test for moisture using a calcium chloride test.

Installation Instructions:



1. Plank Direction should be parallel to the longest wall or in the direction of the room's light source. If these are conflicting, you will need to choose the best aesthetic.
2. Start in the top left of the room with a full plank, Plank A. Continue to assemble the first row engaging the short sides by angling into place. You will need to cut the final piece of the first row to fit the space less than the floor's thickness for expansion.

3. Use the cut off piece left over from row one to start the second row as long as it is 12" or longer. Ensure end joints are staggered at least 6" for best aesthetics. Rotate the long side tongue of this piece, Plank D into the long side groove of Plank A.
4. Install the next plank, Plank E, by angling the short side tongue into the short side groove of Plank D. Ease the tongue and groove together on the long side with Planks A and B by angling the planks together. You may use a white rubber mallet to tap the boards together on the long side. Take care not to damage the boards with the mallet. You may use a scrap piece of flooring as a tapping block.

Note: Do not attempt to engage the long side of the plank and then tap the short sides together. This will cause damage to the integrity of the locking system. The result will be potential joint separation, leaving gaps between the planks.

5. Continue to install planks (Step 4), until the row and subsequent rows are complete. If necessary, use a cutoff piece and white rubber mallet to gently tap the long sides of the boards together.

Note: If the room is greater than 92' (28m) in width or length, field expansion joints are recommended with the use of a T mold or other field expansion molding. Expansion space must also be left at doorways. For large field areas, the flooring can be installed with up to 6000sqft without the use of transitions.

6. To finish the last row, ensure that there is a space between the wall and the last row equal to the thickness of the material for expansion. The last row may require cutting to achieve this expansion space.

Note: Expansion space equal to the thickness of the flooring material must be left around all vertical obstructions such as posts or pipes. Cover any exposed expansion space with appropriate moldings.

7. Once flooring installation is complete, install baseboard or quarter round to cover the expansion space.

Note: A floating floor must be allowed to float and therefore moldings and/or cabinets must be affixed to the walls or subfloor directly allowing the floor to float. Furniture and appliances should be < 230kgs (500lbs) per item. The total weight on the floor should not exceed 19kgs (40lbs) per square foot.

In-floor Radiant Heat:

This floor can be installed over radiant heat using the floating method.

- Turn the heat off for 24 hours before, during and 24 hours after installation when installing over radiant heated subfloors
- Floor temperature must not exceed 85°F (30°C).

Warning: Electric heating mats that are not embedded into the subfloor are not recommended for use underneath this floor. Using electric heating mats that are not embedded and applied directly underneath this floor could void the warranty for your floor in case of failure. It is best to install flooring over embedded hydronic radiant floor heating systems only and adhere to the guidelines listed above.

After Installation

- Flooring should be one of the last items installed in a project. In order to protect the floors while other trades are finishing their work prior to final cleanup, use rosin paper and only use 3M ScotchBlue™ 2080 Tape to hold the rosin paper to the floor (other blue tapes may damage the finish). Clean the floor thoroughly before laying the rosin paper to ensure that no debris is trapped underneath. DO NOT USE plastic film or other non-breathing coverings as this can cause the floor to become damaged from humidity buildups.
- Dust-mop or vacuum your floor to remove any dirt or debris.
- It is suggested that you clean the floor using a recommended laminate cleaner.
- Install any transition pieces that may be needed (reducers, T-moldings, etc.).

Protection and Maintenance of Your Floor

Lasting beauty can be achieved through purchasing a quality floor cleaner (FuzClean laminate or equivalent) and providing proper on-going maintenance.

- Furniture should be moved onto the newly installed floor using an appliance hand truck over hardboard runways.
- Oil or petroleum-based products can result in surface staining. Do not track asphalt-driveway sealer or automobile oil drips onto the floor covering.
- Caster wheeled chairs should have wide, rubber casters. Protective mats are required under office chairs.
- Use non-staining mats. Rubber may discolour the floor.
- Use walk-off mats at entrances to prevent dirt and grit from being tracked on to the floor.

FZN

- Sweep or vacuum the floor regularly to remove loose dirt. DO NOT use vacuums that use a beater bar or turn beater bar off.
- Clean up spills immediately.
- **DO NOT USE:**
 - Electric brooms with hard plastic bottoms with no padding.
 - Harsh cleaners or chemicals on the floor.
 - Abrasive scrubbing tools.
 - Detergents, abrasive cleaners, vinegar or “mop and shine” products.
 - Steam mops.

